


## Remote Sensor for Psychrologix™ Controller

The remote sensor allows the Psychrologix controller to be located in a mechanical room, closet, or other area.

Includes 50 ft. plug-and-play connecting wires.



Psychrologix controller main screen

Simply plug the sensor lead into the marked socket on the bottom of the controller. This action automatically switches off the internal sensor and activates the remote sensor.

You may route the connecting wires through the inside of the unit and out the back, to hide the connecting wires.

For any questions, please contact Chiltrix customer support.

www.chiltrix.com





