


6.5 inch
 The distance from the center of locate hole to the top edge of machine is 6.5 inch


6.5 inch
 The distance from the center of locate hole to the top edge of machine is 6.5 inch



Make sure that the space between two templates is according to the table requirement when installing CXI-34 to CXI-148.

Make sure that the space between two templates is according to the table requirement when installing CXI-34 to CXI-148.

Printing:
 Fedx Office can print this,
 For proper scale, specify
 27-1/4" X 27-1/4"



Model	The distance between two templates(inch)
CXI-34	0
CXI-65	7.87
CXI-85	15.74
CXI-120	23.62
CXI-148	31.50

Model	The distance between two templates(inch)
CXI-34	0
CXI-65	7.87
CXI-85	15.74
CXI-120	23.62
CXI-148	31.50

