

# Wiring / Relay Diagram

This diagram shows how to use a TACO  $\Delta T$  pump for a load side application requiring both heating and cooling. The relay would be connected to the Chiltrix CX34 air to water heat pump seasonal switch terminals. The section above the yellow line is the pump, the section below is the added relays.

