


6.5 inch
 The distance from the center of locate hole to the top edge of machine is 6.5 inch

6.5 inch
 The distance from the center of locate hole to the top edge of machine is 6.5 inch



Make sure that the space between two templates is according to the table requirement when installing PFP 025 to 100.

Make sure that the space between two templates is according to the table requirement when installing PFP 025 to 100.

Water inlet hole

Water outlet hole

Condensation drain hole

Model	The distance between two templates(inch)
CXI-34	0
CXI-65	7.87
CXI-65	15.74
CXI-85	23.62
CXI-120	31.50

Model	The distance between two templates(inch)
CXI-34	0
CXI-65	7.87
CXI-85	15.74
CXI-120	23.62
CXI-148	31.50

The bottom of machine

The bottom of machine

Fold 90 degree along this line

Fold 90 degree along this line

90°

90°

Parallel to the floor

Parallel to the floor

Reserved area for water pipe hole